

Brushes Installation Plate

This installation tool is to hold the brush in the brush plate as you install it.

Direction

1. First load the brushes & springs into the brush plate holder.
2. Cover back side with Plate. (Optional to use the screws to hold holder to plate)
3. Now install both the plate & holder back on engine.
4. If installed remove the screws holding Brush plate to Install plate.
5. Slide the plate out from under the brush plate holder .
6. Screw the brush plate back in place.

